















ИНСТРУКЦИЯ ЗА МОНТАЖ НА ОФИС СТОЛ CARMEN 7561

A		x1	I		M6x20	x4
B		x1	J		M6x30	x6
C		x5	K		M8x20	x3
D		x1	L		ST4x16	x2
E		x1	M		M6	x10
F		x2	N		M5	x1
G		x1				
H		x1				

